

18.11 Spare parts list hose drum

Item	Order no.	Description	Item	Order no.	Description
	0341 910	Hose drum (without high-pressure hose)	11	0341 918	Swivel joint
1	9990 374	Handle	12	9900 108	Hexagon screw M 6 x 20 (4)
2	9920 106	Washer A 10.5	13	9910 204	Hexagon nut M 6 (5)
3	9903 347	Oval head screw M 10 x 20	17	9990 232	Tube clamp
4	0341 461	Drum body	18	9900 106	Hexagon screw M 6 x 12
5	9990 372	Star grip M 8	19	0341 464	Transition socket M 16 x 1.5
6	9900 246	Hexagon screw M 8 x 75	20	9920 614	Shim ring (2)
7	0341 465	Tube	22	0341 466	Washer
8	0341 460	Drum body	23	9922 535	Snap ring 20 x 1.2
9	0341 462	Inner flange	24	9994 962	Plain bearing
10	0341 463	Outer flange		9984 560	High-pressure hose line M 16 x 1.5 (between hose drum and device)

18.12 Spare parts diagram hose drum

