



This manual contains important warnings and information. Read and keep for reference.

INSTRUCTIONS

HSP-10-001 Airless Spray Gun


3600 psi (24.8 MPa, 248 bar) Maximum Working Pressure



⚠ WARNING	
	<p>FIRE AND EXPLOSION HAZARD Solvent and paint fumes can ignite or explode.</p> <p>To help prevent a fire or explosion</p> <ul style="list-style-type: none"> • Use outdoors or in a well ventilated area • Avoid all ignition sources such as static electricity from plastic drop cloths, open flames such as pilot lights, hot objects such as cigarettes, and arcs from connecting or disconnecting power cords and turning light switches off or on. • Tape wall switches to prevent them from being turned off or on. • Use only or Graco airless paint hoses. • Ground sprayer, objects being sprayed, and paint/solvent pails. • Hold metal part of gun firmly to side of a grounded metal pail when triggering into pail • Do not use 1,1,1-Trichloroethane, methylene chloride other halogenated hydrocarbon solvents or fluids containing such solvents in this gun or any other pressurized aluminum equipment. Such use could result in a chemical reaction and an explosion.
	<p>FLUID INJECTION HAZARD High-pressure spray or leaks can inject fluid into the body. If high-pressure fluid pierces your skin, the injury might look like "just a cut," but it is a serious wound. Get immediate medical attention.</p> <p>To help prevent injection</p> <ul style="list-style-type: none"> • Always put gun trigger safety in SAFETY ON position when not spraying. • Always relieve pressure before you check or repair leaks and when you stop spraying. • Never use components rated less than system <i>Maximum Working Pressure</i>. • Never allow children to use this gun. • Never point gun at yourself or anyone else.
	<p>FLUID SPLASHBACK HAZARD To avoid splashback of fluid while spraying, make sure the spray gun is assembled with the correct gasket for the fluid being sprayed. See Installing the Tip on page 4.</p> <p>RECOIL HAZARD Brace yourself. The gun may recoil when triggered.</p>



HSP-10-001 Airless Spray Gun Breakdown & Parts List



*Available as part of a kit

1	AX/00-100-415	X-35 Economy Rev.Tip 415
2	AX/01-300-500	X-50 5000psi Tip Guard 7/8" G Blue
3	AX/01-100-002	X-Series Tip Saddle Only
4	AX/01-100-001	X-Series Tip Seal Only
5	AX/G218-070A	HSP-10-001 Gun Repair Kit (Includes Items 5,6,7 & 10)
8	AX/HSP-10-001A	HSP-10-001 Gun Body
9	AX/HSP-10-001B	HSP-10-001 Retaining Block
11	AX/G218-131	Gun Filter Assembly - Coarse 50 Mesh
12	AX/HSP-10-001C	HSP-10-001 Gun Handle & Swivel